



Hearing & Vision Screening Worksheet (3-5 year old)

West Central Minnesota Communities Action Head Start

411 Industrial Park Blvd., Elbow Lake, MN

p: (218) 685-4486



Child's Name:	Date of Birth:	Age in Years and Months:
---------------	----------------	--------------------------

VISION

Name of Screener:	Date of 1 st Screening	Date of 2 nd Screening:
-------------------	-----------------------------------	------------------------------------

Pre-Screening Assessment *(see back of form)*

Circle Pass or Rescreen for each

Visual Inspection	Pass	Refer
Light Response	Pass	Refer
Cover Test	Pass	Refer

Visual Acuity Screen

Right Eye	Left Eye	Age	Circle Pass, Rescreen or Refer		
10/	10/	3 to 5yr	Pass	Rescreen	Refer
10/	10/	3 to 5yr	Pass	Rescreen	Refer

Notes: _____

HEARING

Name of Screener:	Date of 1 st Screening	Date of 2 nd Screening:
-------------------	-----------------------------------	------------------------------------

Visual Inspection	1 st Screening			2 nd Screening		
External Inspection	Pass	Rescreen	Refer	Pass	Rescreen	Refer

Pure Tone Audiometry

Right Ear	1 st Screening			2 nd Screening		
25dB, 500Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer
20dB, 1000Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer
20dB, 2000Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer
20dB, 4000Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer
Left Ear						
25dB, 500Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer
20dB, 1000Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer
20dB, 2000Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer
20dB, 4000Hz	Pass	Rescreen	Refer	Pass	Rescreen	Refer

Notes: _____

Visual Inspection

- Inspect eye and surrounding area for swelling, discoloration, drainage, etc.
- Inspect position of eyes. Does one or both eyes turn in? Turn out? Is there a head tilt?
- Check whites of eyes for even coloration.
- Iris should be uniform in shape and color in both eyes.
- Pupils should be clear and dark, equal size and circular.
- Lids and Lashes – Lids are flush against the eye; no redness, discharge or styes. Lashes present on upper and lower lids, lashes turn out, normal blinking pattern.

Light Response

1. Position the child so that the target, the light source, and the examiner's line of vision is at the midline in front of the child's eyes at a distance of 14-16 inches.
2. Try to have the child sit with his/her back to any ceiling lights.
3. Shine the penlight at the center of the child's forehead directly above and between the child's eyes.
4. Make sure the child is focused on the target.
5. The screener then observes the reflected light in each pupil.
6. It is very important that good light is used. Ceiling lights are not sufficient.

Cover Test

1. Screener stands in front of and to the side of the child's eye that is being covered.
2. Screener asks child to focus on object at a 10-14 foot distance.
3. Screener covers left and right eyes, alternately, moving occluder vertically from forehead towards cheek while watching the uncovered eye for movement.
4. Uncover eye and ensure vision is fixed on the object.
5. Repeat 2-3 times.
6. Repeat first 3 steps with alternate eye.